

KWIK HUS-EZ I %"

2178150-02.2024



* For non-hole cleaning installation (step 1), make sure to drill deep enough to achieve h1, taking into account the depth of debris remaining in the hole.